

How to **IMPORT HI-8/ANALOG** tape to computer with DV / VHS playback unit

1. Connect the camera via the F-1 input using the RCA (yellow, red, & white) cables
2. Insert mini DV tape into deck
3. Push the DV button, then press Record followed by Pause
4. Make sure to press the S-VHS arrow button so the arrow points to the left, it will turn green
5. Now press the S-VHS button
6. When ready to record, press Play followed by Pause on the camera
7. You may then click Import on the iMovie software, but make sure to unpause the camera



2

1



Make sure this is connected to both computer and playback unit

4

3



5